

All Analog Cameras are Offline

1. Confirm the CCTV power supply is working.

- a. Verify that the power supply is getting power.
 - i. If Not Getting Power -> Move the Power Supply to several different reliable power sources.
 - ii. If Still Not Getting Power -> Relay that information to the help desk
- b. Check if there are any broken fuses:
 - i. If there are one or more broken fuses, replace the fuses if you have them or notify the help desk
- c. Reboot the Altronix power supply.

2. If the PSU does have power, test the voltage on the unit, upload a picture of the test to Field Nation and relay the information to the help desk.

3. Check the whip cable or DVR connections

- a. Confirm the whip cable is securely connected to the EnVR/DVR.
- b. Re-seat the whip cable and reboot the EnVR/DVR.